Gigaware®

26-1438
User's Guide

Battery Pack with Charging Cable for Xbox 360®

Please read this user's guide before using your new battery pack with charging cable.

Package contents

Charging Cable

Battery Pack

Features

- Provides up to 30 hours of playtime with a fully charged battery.*
- Recharges in as little as 4 hours.*
- Play and recharge the battery pack at the same time.

* See **"Important Information"** on page 7 for limitations.

① Install battery pack

Insert the battery pack into your controller, metal contact end first. Press the battery pack to snap into place.



Controller

② Charge battery pack

1. Turn on your Xbox 360 console.
2. Connect one end of the charging cable to your controller.





3. Connect the other end to your Xbox 360 console's USB port.
4. When the battery pack is fully charged, unplug the charging cable from your controller and console.

⚠ ***Caution:*** *Do not connect the charging cable if a non-rechargeable battery pack is installed. This may damage the controller.*

Notes:

- *You can play and charge the battery pack at the same time. To continue charging after game play, simply turn off your Xbox 360 console but leave the charging cable connected.*
- *To charge the battery pack when not playing a game, you must turn on your Xbox 360 console before connecting the controller to start the charging process. You can then switch off your console to continue charging.*

Recycle Rechargeable Batteries

Recycle your old rechargeable batteries at one of the many collection sites in the U.S. and Canada. To find the site nearest you, visit www.call2recycle.org or call toll-free 1-877-2-RECYCLE.

Important Information

- Do not touch the battery pack's charging contacts with your fingers or with metal material.
- The rechargeable battery pack provides up to 30 hours of play per charge.
- Fully charging the battery pack takes up to 4 hours. A very depleted rechargeable battery pack can take longer to charge.
- Repeatedly charging a battery pack that is not fully discharged can shorten the life of the battery pack.
- Charge the battery pack on a fireproof surface away from flammable items or liquids.
- The battery pack gradually loses power when stored or not in use. For optimal performance, recharge prior to using the controller.

- The battery pack normally becomes warm during charging or use.
- To fully charge a battery pack with higher capacities, run the battery pack through three consecutive charging cycles.
- If the battery pack's charging contacts are dirty or tarnished, clean them with a dry cloth.
- The amount of game play time will decrease as the battery pack ages or after many recharge cycles. Replace the battery pack when it cannot be charged anymore, or the game play time shortens.
- Using the controller to play a game while battery pack is charging might increase charging time. Games with vibration feature might also increase charging time.

Specifications

Ni-MH Battery Pack 2100mAH, 2.4V
Charging Cable .....12 ft. (3.66 m)
Recharging Time .....4 hours
Battery Life ..... 30 Hours per charge
Battery Capacity .....2100mAH (standard)
.....1620mAH (min.)
Battery Life Cycle..... 500 Times (min.)
Connectors .....USB A type male
.....XBOX 360 7-pin
Operating Temperature ... 32°F–104°F (0°C–40°C)
Recharging Cable Weight..... 3.53 oz (100 g)
Battery Pack Weight..... 2.3 oz (65 g)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

Protect the environment by recycling used electronics. Go to E-CyclingCentral.com to find an electronic recycling center near you.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Ignition L.P. may cause interference and void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Product	Battery Pack with Charging Cable for Xbox 360®
Model	26-1438
Responsible Party	Ignition L.P. 3102 Maple Ave Suite 450 Dallas, TX 75201
Phone	866-315-0426

Limited Warranty

Ignition L.P. warrants this product against defects in materials and workmanship under normal use by the original purchaser for **one (1) year** after the date of purchase. IGNITION L.P. MAKES NO OTHER EXPRESS WARRANTIES.

This warranty does not cover: (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident, Acts of God (such as floods or lightning), or excess voltage or current; (b) improper or incorrectly performed repairs by persons who are not a Ignition L.P. Authorized Service Facility; (c) consumables such as fuses or batteries; (d) ordinary wear and tear or cosmetic damage; (e) transportation, shipping or insurance costs; (f) costs of product removal, installation, set-up service, adjustment or reinstallation; and (g) claims by persons other than the original purchaser.

Should a problem occur that is covered by this warranty, take the product and the sales receipt as proof of purchase date to the place of purchase. Ignition L.P will, at its option, unless otherwise provided by law: (a) repair the product without charge for parts and labor; (b) replace the product with the same or a comparable product; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of Ignition L.P. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

IGNITION L.P. EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND, IF APPLICABLE, THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXPIRE ON THE EXPIRATION OF THE STATED WARRANTY PERIOD.

EXCEPT AS DESCRIBED ABOVE, IGNITION L.P SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO THE PURCHASER OF THE PRODUCT OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE AND ANY LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF IGNITION L.P. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State. You may contact Ignition L.P. at:

Ignition L.P., 3102 Maple Ave Suite 450, Dallas, TX 75201 02/09

For product support, call **1-866-315-0426.**

© 2009. Ignition L.P. All rights reserved.
Gigaware is a registered trademark used by Ignition L.P.
Xbox 360 is a registered trademark of Microsoft Corporation.

Printed in China 06A09 26-1438